
# Industrial Track Mount Switch Set



WWW.GRISK.COM

## 4700-A Series

- ♦ Reversible probe assembly
  - ♦ Left or right installation
    - ♦ Reversible cable exit
- ♦ 3 ft. armored cable standard
- ♦ Multi position adjustable magnet bracket
  - ♦ Close loop or SPDT
- ♦ Hinge design for tighter clamping to track
  - ♦ Up to 3" gap
  - ♦ Fits channels from 1.75" up to 4"
    - ♦ Self drilling screws included for easy installation
  - ♦ Contacts are on the channel and not where they can get damaged on the floor
    - ♦ No special tools required for installation



The 4700-A Series switches are designed to be easy to install and very adjustable. They can attach to a wide range of track sizes and only require tightening one or two screws to install the contacts. It can be installed on either side of the door and the cable exit can be reversed to simplify installation.

And adjustable magnet bracket extends the reach on particularly difficult installations and self drilling screws shorten installation times. Also with a gap of up to 3 inches, doors that wear and get misaligned are not a problem.

Part Numbers									
Track Size	Closed Loop	<u>SPDT</u>	<u>DPDT</u>						
1.75" to 2.75"	4700-A	4701-A							
2.5" to 4"	4700-AXL	4701-AXL	4705-AXL						
Gap up to 3"									



WWW.GRISK.COM

4700-A

# Industrial Track Mount Switch Set



WWW.GRISK.COM

### INSTALLATION APPLICATIONS


Select a location on the channel that will be out of the way during normal use of the door. The switch can be located anywhere along the channel. This location should also have a matching location on the door when it is in the closed position that the magnet can be attached to.


If necessary reverse the armored cable by removing the screw opposite the cable and moving the probe to the opposite side of the switch. Then just reinstall the screw.

Before assembling the switch, back out the hex head screw until the end is flush with the switch body. Assemble the switch by sliding the hinge plate into the slot on the switch and inserting the L shaped bracket into the other slot on the switch. (XL version: Install the countersink screw and nut through switch body and L shaped bracket. Snug nut up letting L shaped bracket still slide.) Optional: Install piece of double stick tape on the inside of short side of L shaped bracket to prevent movement from the track vibration.) Then squeeze the switch assembly around the channel making sure the switch locks into a slot on the L shaped bracket. (XL version: Tighten the nut making sure that the switch stays in the slot on the L shaped bracket.) Then just tighten the hex head screw to firmly attach switch to channel.

The magnet is installed by locating a position on the door that will be out of the way as the door is opened and closed. The magnet should be placed vertically and so that it will stay in range of the switch as the door wears or moves around. There are multiple mounting positions on the magnet bracket in order to make finding the mounting position easier.

### Hand tighten screws. Do not over tighten.





#### GRI PRODUCTS MEET OR EXCEED THESE MINIMUM GENERAL SPECIFICATIONS:

		Electrical	Reed	Max. Initial Contact	Max. Contact	Max. Switching	Max. Switching
Part Number	Loop Type	Configuration	Form	Resistance (Ω)	Rating (W)	Voltage (VDC)	Current (A)
4700-A	Closed	N/O	Α	.150	10	160	.400
4701-A	Open/Closed	SPDT	C	.140	5	175	.250
4700-AXL	Closed	N/O	Α	.150	10	160	.400
4701-AXL	Open/Closed	SPDT	C	.140	5	175	.250
4705-AXL	Open/Closed	DPDT	CX2	.140	5	175	.250

WARRANTY: Lifetime warranty against workmanship, material and factory defects.

GEORGE RISK INDUSTRIES, INC.

G.R.I. PLAZA

**KIMBALL, NE 69145** 



1-800-445-5218 1-800-523-1227 (308) 235-4645

FAX (308) 235-3561 E-MAIL: sales@grisk.com